



Versandanschrift
Address
Adresse du destinataire
Indirizzo di trasporto
Dirección de expedición

Fax.-No

Ersatzteilliste
Spare parts list
Liste des pièces de rechange
Elenco parti di ricambio
Lista de piezas de repuesto

1274396	TruTool F 140 (1A1)	D	230V 50Hz
1274399		CH	230V 50Hz
1274422		GB	110V 50Hz
1254057		USA	120V 50/60Hz
1274425		PL	230V 50Hz

NO.	D'ORDINE NO. DE REF. NO. DE REF. ORDER. NO. NO	PEZZO DI RICAMBIO PIEZA DE RECAMBIO PIECE DE RECHANGE SPARE PART BEST.-NR. ERSATZTEIL	DIN	QUAN. CANT. QUAN. QUAN. STK.
1	0003530			
2	0019410	M4x6-10.9	ISO 7380	
3	0003523			
4	0012254	3x3x10-St50K	DIN 6885	
5	0027260	HK 1414-RS		
6	0110327	0.6-1.0mm		
	0110331	1.0-1.4mm		
7	0077526	630/8-2RS	DIN 625	
8	0018740	M3.5x22	DIN 84	
9	0035758			
10	0019410	M4x6-10.9	ISO 7380	
11	0047324	4.3x12		
14	0023181			
15	0003532			
16	0011452	4x18-FDST	DIN 7344	
17	0003531			
19	0003519			
20	0021091	8x0.8-FDST	DIN 471	
21	0011622	6x20-FDST	DIN 1481	
22	0028390			
23	0028389			
24	0012173	M6x22-12.9	DIN 912	
25	0003514			
26	0011037	12m6x55	DIN 6325	
27	0003522			
28	0027740	6000-Z	DIN 625	
29	0003528			
30	0021113	10x1-FDST	DIN 471	
31	0003525			
32	0003527			

33	0003515		
34	0094316	OR 120x7	OR 8475
35	096092		
36	0013269	M8x20-45H	DIN 913
37	0029173		
38	0013846	M5x8-45H	DIN 914
39	0003516		
40	0019526	M5x12-12.9	ISO 7380
41	0003529		
42	0021474	32X1.2-FDST	DIN 472
43	0027804	6002-Z	DIN 625
44	0003526		
45	0023698	8x14x0.3 St50K	DIN988
46	0027251	HK 0808	
47	0021440	26x1.2-FDST	DIN472
48	0035772		
49	0012238	3x3x6-St50K	DIN 6885
51	0035756		
52	0010677	4m6x14 St60	DIN 6885
53	0018074	M4x20-10.9	DIN 7991
54	0027693		DIN 625
55	0096094		
56	0016527	M5x6h8x10	ISO 7379
57	0096087	mm	
58	096088	mm ALU	
59	096089	GA	
60	096090	GA ALU	
61	102200		
90	0105084		
92	0035395		
93	0035770		
94	0028458		
136	0018139		

