


CIRCUIT BEVELER ECB-0203 ASSEMBLY AND PARTS LIST



The part numbers with () are included in the Ass'y parts written above them.

No.	Part No.	Part Name	Q'ty	Price
1	TA91354	Sub Handle Ass'y	1 set	
2	TP16126	Grip Guard	1	
3	TQ03648	Bearing Case	1	
4	TP15163	Pan Head Screw 4X35	4	
5	TP00144	Washer M4	3	
6	TP02797	Pan Head Screw 4X6	3	
7	TP01924	Hex. Nut M6	1	
8	TB02856	Guide Sleeve ϕ 22 Ass'y	1 set	
9	TQ01629	Indexable Insert Set Screw 4X7	1	
10	TQ01628	Indexable Insert With Hole 12.7	1	
11	TQ03649	Holder	1	
12	TP06385	Ball Bearing 6904ZZ	2	
13	TQ03650	Spacer 20.1X25X5	1	
14	TQ03651	Spacer 31.1X36.9X5	1	
15	CP03040	External Retaining Ring C-20	1	
16	TQ03655	Adjust Ring	1	
17	TP08389	Spring Pin 4X24	4	
18	TP07118	Hex. Socket Head Cap Screw 6X16	1	
19	TQ03658	Lever	1	
20	TQ03659	Lock Wire	1	
21	TQ03660	Stopper	1	
22	TQ03656	Swing Ring	1	
23	TQ03657	Circle Plate	1	
24	TP02750	Countersunk Head Screw 4X12	3	
25	TQ00827	Spindle	1	
26	TQ01370	Parallel Key both ends round 4X4X18	1	
27	TP03755	Woodruff Key 2.5 x10	2	
28	TP16195	Dust Seal	1	
29	TP16119	Bearing Case	1	
30	TP03675	Ball Bearing 6200ZZ	1	
31	TP01173	Internal Retaining Ring C-30	1	
32	TB01097	Pinion Gear Ass'y	1 set	
33	TP04595	External Retaining Ring C-10	1	
34	TB00609	Gear Case Sub Ass'y	1 set	
35	TP16208	Pan Head Tapping Screw 4X16	6	

No.	Part No.	Part Name	Q'ty	Price
36	TP04234	Spring Washer M4	10	
37	TQ00422	Bowed Retaining Ring E BETW-6	1	
38	TP11779	Ball Bearing 629DD	1	
39	TP16252	Bearing Supporter	1	
40	TP11245	Pan Head Screw 4X10	2	
41	TA9A446	Rotor Sub Ass'y	1 set	
42	TP16251	Ball Bearing 627ZZ	1	
43	TP16254	Pan Head Screw 4X60	2	
44	TA9A444	Stator Ass'y	1 set	
45	TP16213	Brush Cap	2	
46	TA9A633	Caron Brush Ass'y	1 set	
47	TP16266	Insulation Seat Metal	2	
48	TB04293	Motor Case Ass'y	1 set	
49	(TQ05455)	Label Warning	1	
50	(TP16216)	Plate Nitto	1	
51	TP16256	Insulation Stand	1	
52	LP12832	Pan Head Tapping Screw 4X14	4	
53	TQ03965	Capacitor SKT	1	
54	TA99917	Switch Ass'y	1 set	
55	TA99916	Switch Lever Ass'y	1 set	
56	TP16261	Cord Clamp	1	
57	TP16262	Cord Stopper	1	
58	TP04235	Pan Head Screw 4X8	2	
59	TP16255	Motor Cover	1	
60	TP16292	Pan Head Screw 3.5X8	4	
61	TB02514	Electric Cord Ass'y	1 set	
62	TP04075	Spring Washer M4	4	

ACCESSORIES

	TP04004	Hex. Socket Screw Key 5	1	
	TQ03654	Ball Bearing 687ZZ	1	
	TP17014	Spanner 8X10	1	
	TQ01683	Spanner T-15D	1	
	TQ01629	Indexable Insert Set Screw 4X7	1	
	TB01138	Indexable Insert with Hole 12.7 Ass'y	1	
	TQ03961	Gauge C3	1	