


# AIR SONIC L-25B ASSEMBLY AND PARTS LIST



The part numbers with ( ) are included in the Ass'y parts written above them.

No.	Part No.	Part Name	Q'ty	Price
1	TB01475	Housing Sub Ass'y	1 set	
15	(TQ02058)	Label Warning	1	
2	TP06117	Waved Spring Washer 12X16X0.3	1	
3	TP03933	Ball Bearing 606ZZ	1	
4	TP06119	End Plate A	1	
5	TP06121	Cylinder	1	
6	TP06321	Rotor	1	
7	TA9A287	Blade Ass'y (4 pcs.)	1 set	
8	TP06322	Spacer 8X11X3	1	
9	TP00496	Spring Pin 2.5X6	1	
10	TP14931	End Plate B	1	
11	TP00468	Ball Bearing 608ZZ	1	
12	TB01630	Lock Ring Ass'y	1 set	
28	(TP12437)	Label Rotating Direction	1	
29	(TQ02207)	Label Warning CE Mark	1	
13	TA96328	Chuck Ass'y	1 set	
	TA96329	Chuck Ass'y (inch)	1 set	
14	(TP10742)	Chuck Nut	1	
16	TA93070	Throttle Valve Ass'y	1 set	
17	TP06325	Adjust Valve	1	
18	TP11997	O-Ring KS-7	1	
19	TP06326	Spacer 6X12X1.2	1	

No.	Part No.	Part Name	Q'ty	Price
20	TP03695	Retaining Ring C-12	1	
21	TA96867	Air Hose Sub Ass'y A 1/4	1 set	
22	TQ01664	Exhaust Hose	1	
23	TP09153	Stop Ring	1	
24	TB01152	Throttle Lever Ass'y	1 set	
25	(TP05498)	Spring Pin 2X16	1	
26	(TP00460)	Spring Pin 3X22	1	
27	TP12435	Spring Pin 2.5X10	1	

## ACCESSORIES

	TP00475	Single Ended Spanner 14	1	
	TP00477	Mounted Wheel No.2	1	
	TP00478	Mounted Wheel No.3	1	
	TP03840	Chunk Pin	1	
	TQ04067	Instruction Manual	1	
	TQ04068	Instruction Manual (USA)	1	
	TP02236	Bushing PT1/4XNPT1/4	1	