


# MYTON MAG-25B ASSEMBLY AND PARTS LIST



The part numbers with ( ) are included in the Ass'y parts written above them.

No.	Part No.	Part Name	Q'ty	Price
1	TP10826	Packing	1	
2	TP10100	Bearing Cover	1	
3	TP03933	Ball bearing 606ZZ	2	
4	TP14225	Gear	1	
5	TP00468	Ball Bearing 608ZZ	2	
6	TA98808	Bearing Set Screw Ass'y	1 set	
7	TP17961	Spindle	1	
8	TB01668	Wheel Guard Ass'y	1 set	
36	(TQ02362)	Label Warning for Wheel Guard	1	
9	TP17962	Outer Flange	1	
10	TP14222	Cylinder	1	
11	TA9A295	Blade Ass'y (4 pcs.)	1 set	
12	TP14224	Rotor	1	
13	TP14931	End Plate B	1	
14	TP06322	Spacer 8X11X3	1	
15	TP14221	Pinion	1	
16	TB01669	Housing Ass'y	1 set	
37	(TQ02207)	Label Warning CE Mark	1	
17	(TP06715)	Raised Countersunk Head Screw 5X8	1	
18	TP14227	Exhaust Cover	1	
19	TP14228	Exhaust Plate	2	
20	TP15164	Pan Head Screw 4X16	1	
21	TP00496	Spring Pin 2.5X6	1	
22	TP10109	End Plate A	1	
23	TP10110	Cap	1	

→ HF 9041416

No.	Part No.	Part Name	Q'ty	Price
24	TP10098	Adapter	1	
25	TP03468	Lock Ring	1	
26	TP03695	Internal Retaining Ring C-12	1	
27	TP06326	Spacer 6X12X1.2	1	
28	TP11997	O-ring KS-7	1	
29	TP06325	Adjust Valve	1	
30	TA93070	Throttle Valve Ass'y	1 set	
31	TB01251	Valve Body Sub Ass'y	1 set	
38	(TQ02380)	Label Warning MAG-25B	1	
32	TB01152	Throttle Lever Ass'y	1 set	
33	(TP00460)	Spring Pin 3X22	1	
34	(TP05498)	Spring Pin 2X16	1	

## ACCESSORIES

	TP18000	Abrasive Wheel AC #80	1	
	TP04004	Hex. Socket Screw Key 5	1	
	TP00475	Single Ended Spanner 14	1	
35	TP02236	Bushing PT 1/4XNPT 1/4	1	
	TQ02364	Instruction Manual	1	